

APPENDIX 1 SEA SCAMP SAFETY BRIEFING 2021

- GAS** Cylinder tap "ON" when boat in use
Galley tap "OFF" when stove not in use.
Stove taps "OFF" before closing galley tap.
If Gas or Carbon Monoxide Alarm sounds or leak suspected use bilge pumps AND forced ventilation.
- FIRE** Extinguishers located :
One at forward end of saloon mounted under bookcase
One in saloon port lower middle locker.
One mounted on side of coachroof, port side, by companionway.
One automatic extinguisher in engine compartment.
One Fire Blanket on starboard half bulkhead adjacent to cooker.
- LIFEJACKETS** Demonstrate how to fit and operate them (including light, spray hood and lanyard).
They MAY be worn at anytime by any crew member and **MUST** be worn :
in heavy weather (second reef in mainsail or true wind speed 20 knots plus).
between sunset and sunrise.
when visibility is below one nautical mile (due to rain, spray, mist or **fog**).
by anyone being sea sick.
whenever the Skipper instructs.
- PRECAUTIONS** BOOM - do not stand where it can hit you.
HOLD ON with one hand (one for the job, one for the boat).
SAFETY LANYARDS – how and when to use.
STRONG POINTS for attaching lanyard - mast, standing (**not** running) rigging, jackstays.
- In cockpit – use when coming from below in rough weather.
- WINCHES** Control release of sheet under tension by pressing palm of one hand against the turns on the drum, but take care to keep fingers clear.
Demonstrate how to put extra turns on and the use of the self-tailer.
- MOB** STOP the boat ! Helm pushed immediately towards boom as far as it will go and held there until instructed otherwise by Skipper. Take in all slack from sheets as boat heads up.
Shout "MAN OVERBOARD" three times (including below decks).
Lookout, not the Helm, standing at stern points at victim and stays pointing
Activate MOB function on GPS set at earliest opportunity.
Dan Buoy / lifebuoy thrown overboard only when victim can reach them (unless running).
OSCAR / Lifesling only used when boat has stopped.
Skipper (or Mate) will give further instruction re. manoeuvring and pick up.
- FLARES / VHF MAYDAY / LIFERAFT / GRAB BAG / EPIRB / AIS**
ONLY USE IF LIFE IS IN DANGER AND ON DIRECT ORDERS OF SKIPPER (Mate if Skipper is incapacitated).
Point out where each item is stowed and contents of Grab Barrel.
Explain VHF Mayday procedure (inc. use of DSC Alert).
Brief explanation of different types of flare and their operation.
Brief explanation of how to deploy liferaft (warn crew **NOT** to pull lanyard inadvertently).
Brief explanation of use of EPIRB and AIS

LOCATION AND OPERATION OF NAVIGATION LIGHT SWITCHES, ENGINE CONTROLS, BOLT CROPPERS, EMERGENCY TILLER, AND SEACOCK BUNGS

Anyone with a medical condition that could affect them whilst sailing must disclose it to the Skipper
© Sea Scamp Syndicate Sailing Manual (2nd Edition) 2021

SEA SCAMP GRAB BARREL CONTENTS

- Dextrose Tablets & High Energy Food
- Cup + 60 ml measuring cup
- Whistle
- Lightweight rope.
- Sun cream
- Survival Blankets (4) - (2 more in liferaft)
- Torch and spare AAA batteries
- Light weight hand towel
- Polythene bags
- Light Sticks - 2 x 12 hrs
- Signalling Mirror = CD-Rom
- SOLAS - V/29 - Life Saving Signals
- Waterproof notepad and pencils

SEA SCAMP LIFE RAFT SOLAS B PACK CONTENTS

The Solas B emergency pack is carried within the liferaft and is accessible once the liferaft is inflated. It contains :

- Bellows
- Paddles (2)
- Repair Kit
- Valve Plugs (2)
- Radar Reflector
- Leak Stoppers
- Sponges (2)
- Signalling Torch (+ spares)
- Rescue Quoit & line
- Floating Knife
- Emergency Instructions Procedure
- Sea Anchors (2)
- Thermal Protective Aids (2)
- Whistle
- Heliograph
- First Aid Kit
- Hand Flares (3)
- Rocket Parachute Flares (2)
- Buoyant Smoke Signal (1)
- Bailer
- Rescue Signal Tables (Solas 2)
- Anti-Seasickness Tablets (6 per person)
- Plastic Bags (1 per person)

SEA SCAMP FLARE PACK

Sea Scamp's flares are stored in a blue waterproof container under the chart table. This contains :

- Red Parachute Flares (4 off)
- Red Handheld Flares (4 off)
- Orange Smoke Signals (2 off)

And a pair of thick gloves and safety spectacles.

There are also two white handheld (collision warning) flares mounted in spring clips on the inside of the coachroof coaming just above the port quarter berth.

Note too that additional flares are carried in the liferaft's Solas B Pack (above).

APPENDIX 2 STOWAGE PLAN 2021

This plan varies from time to time, dependent on *Sea Scamp's* area of operation and cruising ground, but generally she has an inventory including the following basic items and stowage points.

It will save a lot of time and trouble if this plan is adhered to it is particularly important in an emergency when time spent searching for a piece of equipment could put lives at risk

A 2.1 SAFETY EQUIPMENT

AIS transponder	Chart table display rack
Bolt Cutters	Saloon locker – starboard forward lower
Dan Buoy	Mounted along guard rail, starboard side aft
Emergency Tiller	Forepeak – by Harbour Board
EPIRB	Starboard quarter berth –forward bulkhead
Fire Blanket	Starboard half bulkhead next to cooker
Fire Extinguishers	Saloon below bookcase (1 off)
	Port side of coach roof, inside companionway (1 off)
	Saloon locker – port middle lower
	Engine compartment – automatic
First Aid Kit	Under chart table – aft locker
Flares	Blue plastic container underneath chart table
	2 white collision flares inside coach roof to port
Fog Horn	large Drawer under chart table
Grab Barrel	Mounted on coach roof coaming, forward of chart table
Hand Bearing Compasses	In cuddy on forward bulkhead, starboard quarter berth
Handy Billy	Forepeak – lashed to beam shelf above water tank
Heaving Line	In large drawer under chart table
Life Buoys	2 On the pushpit
Lifejackets incl harness safety lines & lights	On hooks above water locker
Lifejackets – spare rearming kits	Plastic box in large chart table drawer
Life Sling	On the guard rails, port side aft
Life Raft	Secured to the coach roof
Navigation lights – emergency	Plastic box – port middle lower locker
Safety harnesses & lanyards – 2 (Mast climbing)	Bosun's locker under chart table
Sea Cock Bungs	Appropriate size tied to each sea cock
VHF Radio – hand held	In charger at forward end of port quarter berth
VHF Radio – mains charger	Saloon locker – port middle lower
Windows – wooden blanks	Saloon locker – starboard forward lower

A 2.2 GENERAL EQUIPMENT

Anchor Ball		Bosun's locker under chart table
Anchor Light		Large drawer under chart table
Antifreeze		Lazaret
Awning _ Boom tent		Port guardrail inside dodger
AWNING – Forehatch		Kedge Locker
Barometer		Above the chart table
Batteries (Dry)		Saloon locker – starboard forward upper
Batteries (Wet; engine and ship's)		Under companionway step
Battery charger		Saloon half bulk head forward of chart table
Bell – Ship's		Lazaret – portside forward
Bilge Pumps	1	Lazaret, operated from aft end of cockpit
	2 Large capacity	Under companionway step
	3 Electric	Bilges forward of engine compartment
Bilge Pump Handles 1		Companionway handle stowage bin
	2	Under chart table
Boat Hooks		Tied to coach roof grab rails
Bosun's Chair		Bosun's locker under chart table
Buckets		Lazaret
Bulbs (Torch and Nav. lights)		Saloon locker – starboard forward upper
Bungs		Saloon locker – starboard forward upper
Burgee		Shelf above chart table
Sailing fee Sheets		Chart table bookcase – White ring binder
Charts		In the chart table locker & small drawer
Chummy – anchor cable weight		Kedge locker
Clock		Forward coach roof upper bulkhead
Cordage		Saloon locker – port forward lower
Courtesy Flags		Behind First Aid kit in locker under chart table
Data Files		Chart table bookcase
Deck Brush		Lazaret
Depth Sounder & Speed display		Coachroof aft panel facing helm ,starboard side
Depth Sounder Transducer		Saloon locker – starboard forward lower
Dinghy		Forepeak – kedge locker
Dinghy oars		Forepeak starboard side aft by mast
Dinghy repair kit		Saloon locker – starboard forward upper

Dividers	Chart table
Dummy Log Transducer	Saloon locker – port forward lower
Dustpan and Brush	Under the chart table
Electrical Shore Leads	Saloon locker – port middle lower
Electrical Spares	Saloon locker – starboard forward upper
Engine Oil	Lazaret
Engine Spares	Starboard quarter berth locker - aft
Ensign	Stowed wrapped around its staff in the port Q/berth
Fenders	Forepeak
Fishing rod & tackle	Spare gas cylinder locker -lazaret
Fuel (Diesel) – in use	57 litre (13 gallon) tank under cockpit sole
Fuel (Diesel) – spare	Jerrys in Lazaret
Fuel (Outboard)	In locker mounted on pushpit
Gas Bottle - in Service	Locker on deck, aft of mainsheet
Gas Bottles – Spare	Locker in Lazaret, starboard side
Grease, Oil & Sealants	Saloon locker – port forward upper
Harbour mooring board	Forepeak – forward on starboard side
Hose – fresh water	Forepeak aft on shelf above kedge locker
Jubilee / Pipe Clips	Saloon locker – starboard forward lower
Jump Leads	Saloon locker – port middle lower
Kedge Anchor & Warp	Forepeak locker – starboard side
Keys for the Main Hatch Padlock	Hanging on a hook inside Lazaret on the starboard side (just below your left knee !)
Keys for the Outboard & Store	Chart table hook
Lead Line	Locker under chart table
Log Impeller	Saloon locker – port forward lower
Mainsail Cover	Forepeak
Motor Sailing Cone	Bosun's locker under chart table
Nuts and Bolts	Saloon locker – starboard forward upper
Oil, grease & sealants	Saloon locker – port forward upper
Outboard Motor	Padlocked onto the pushpit
Outboard Fuel	Locker on pushpit
Outboard Oil	Lazaret
Paint and Varnish	Lazaret (grey container, port side)
Palm and Needles	Saloon locker – starboard forward upper
Pipe / Jubilee Clips	Saloon locker – starboard forward lower

Preventer		Forepeak – hanging from beamshelf- starboard side
Pump Spares		Starboard quarter berth locker - aft
Radio		Forward end of starboard quarter berth
Rigging Spares		Saloon locker – starboard forward lower
Sails	Spinnaker & Asymmetric	Forepeak – forward section
	Heavy Genoa	Forepeak – forward section
	No. 1 Jib	Forepeak – forward section
	No. 2 Jib	Forepeak – forward section
	Storm jib & Trysail	Forepeak – forward section
Sail Cover (Main)		Forepeak
Sail repair kit		Saloon locker – starboard forward upper
Sail cloth		Saloon locker – port middle lower
Screws		Saloon locker – starboard forward upper
Sealants, Grease & Oil		Saloon locker – port forward upper
Shackles		Saloon locker – starboard forward lower
Shapes (balls & cone)		Bosun's locker under chart table
Sheets (Jib and Spinnaker)		Forepeak – hanging from beam shelves
Ship's Papers		In a Data File in the chart table bookcase
Signal Flags		In flag roll, tied to bulkhead at foot of port Q berth
Signal Lamp /searchlight		Large drawer under chart table
Soldering iron		Starboard quarter berth locker - aft
Spinnaker Pole		Forward deck – port side
Tiller (Spare)		Forepeak – kedge locker
Tools	Bolt Cutters	Saloon locker – starboard forward lower
	Electrical	Saloon locker – starboard forward upper
	Socket Set	Port quarter berth locker
	Tool boxes	Starboard quarter berth locker - forward
Torches		Shelf above chart table
Trailing Log		Saloon locker – starboard forward lower
VHF Aerial (Spare)		Port quarter berth; grey tube under beam shelf
VHF Set		Under deck in port quarter berth
Warps		Forepeak, hanging neatly from beam shelves
Water Tank		Forepeak – port aft locker
WD 40		saloon locker – port forward upper
Winch Handles		Handle stowage bin in companionway
Windows – wooden blanks		Saloon locker – starboard forward lower

